



Diagram / Parts List

DHW180

CORDLESS PRESSURE WASHER



| | |
|-----------|--------------|
| IN | INDIA |
|-----------|--------------|

DHW180 / CORDLESS PRESSURE WASHER

| Item | Sub | Parts No. | Parts Description | Qty | I/C | E/C No. | Close No. | Remark |
|------|-----|------------|--------------------------------|-----|-----|---------|-----------|--------|
| 001 | | LX00000005 | TAPPING SCREW ST3X12 | 15 | | | | |
| 002 | | LX00000006 | NAME PLATE EU | 1 | | | | |
| 003 | | LX00000071 | HOUSING SET | 1 | | | | |
| | C10 | 263005-3 | RUBBER PIN 6 | 2 | | | | |
| 004 | | LX00000008 | WIRE GROMMET 2 HOLES | 1 | | | | |
| 005 | | LX00000009 | ROUND SEAL 2X200 | 1 | | | | |
| 006 | | LX00000010 | WIRE GROMMET 4 HOLES | 1 | | | | |
| 007 | | LX00000072 | OUTLET PIPE COMP. | 1 | | | | |
| 008 | | LX00000011 | SILICONE RING 17 | 1 | | | | |
| 009 | | LX00000012 | O-RING 15.5X2 | 1 | | | | |
| 010 | | LX00000013 | U TYPE PIN 2.5X18.5 | 1 | | | | |
| 011 | | LX00000014 | PUMP MOUNT PAD | 1 | | | | |
| 012 | | LX00000015 | MOTOR & PUMP ASSY | 1 | | | | |
| | C10 | LX00000016 | MOTOR WITH PINION GRAR COMP. | 1 | | | | |
| | C20 | LX00000017 | PAN HEAD SCREW M4X12 | 2 | | | | |
| 013 | | LX00000014 | PUMP MOUNT PAD | 1 | | | | |
| 014 | | LX00000018 | SWITCH | 1 | | | | |
| 015 | | LX00000019 | CONTROLLER UNIT | 1 | | | | |
| 016 | | LX00000020 | LEAD UNIT 18AWG 210MM RED | 1 | | | | |
| 017 | | 644809-6 | TERMINAL | 1 | | | | |
| 018 | | LX00000021 | U TYPE PIN 2.5X11.5 | 1 | | | | |
| 019 | | LX00000022 | VALVE | 1 | | | | |
| 020 | | LX00000023 | CONICAL SPRING 7-9X20 INOX | 1 | | | | |
| 021 | | LX00000073 | INLET VALVE SET | 1 | | | | |
| | D10 | | INC. 22-31 | | | | | |
| 022 | | LX00000024 | O-RING 8.6X1.7 | 1 | | | | |
| 023 | | LX00000025 | U TYPE PIN 2X16 | 1 | | | | |
| 024 | | LX00000026 | INLET VALVE PLUG | 1 | | | | |
| 025 | | LX00000027 | O-RING 12 | 1 | | | | |
| 026 | | LX00000028 | O-RING 5.3 | 1 | | | | |
| 027 | | LX00000029 | PLASTIC WASHER 6 | 1 | | | | |
| 028 | | LX00000030 | COMPRESSION SPRING8.5X39 INOX | 1 | | | | |
| 029 | | LX00000031 | INLET VALVE STEM | 1 | | | | |
| 030 | | LX00000032 | O-RING 4.5 | 1 | | | | |
| 031 | | LX00000033 | INLET VALVE BODY | 1 | | | | |
| 032 | | LX00000034 | LINK ROD | 1 | | | | |
| 033 | | LX00000035 | TRIGGER | 1 | | | | |
| 034 | | LX00000036 | COMPRESSION SPRING7.5X25 INOX | 1 | | | | |
| 035 | | LX00000037 | TRIGGER LOCK | 1 | | | | |
| 036 | | LX00000038 | INDICATOR LAMP LENS | 1 | | | | |
| 037 | | LX00000039 | LEAF SPRING INOX | 2 | | | | |
| 038 | | LX00000040 | SPEED CHANGE LEVER | 1 | | | | |
| 039 | | LX00000041 | SERIAL NUMBER LABEL | 1 | | | | |
| 040 | | LX00000043 | BATTERY CASE SEAL RING | 1 | | | | |
| 041 | | LX00000044 | BATTERY CASE LATCH | 1 | | | | |
| 042 | | LX00000045 | CONICAL SPRING 5-10X6.3 INOX | 1 | | | | |
| 043 | | LX00000046 | BATTERY CASE | 1 | | | | |
| 044 | | LX00000047 | WARNING LABEL | 1 | | | | |
| 045 | | LX00000049 | EXTENSION PIPE 350MM ASSY | 1 | | | | |
| | D10 | | INC. 46 | | | | | |
| 046 | | LX00000076 | O-RING 9.5X2.65 | 1 | | | | |
| 047 | | LX00000050 | 5 PATTERNS SPLAYER NOZZLE ASSY | 1 | | | | |
| | D10 | | INC. 48-55 | | | | | |
| 048 | | LX00000077 | 5 PATTERNS SPLAYER NOZZLE | 1 | | | | |
| 049 | | LX00000051 | COMPRESSION SPRING5.2X12 INOX | 1 | | | | |
| 050 | | LX00000052 | STEEL BALL 7/32" | 1 | | | | |
| 051 | | LX00000053 | O-RING 7.5X2.5 | 1 | | | | |
| 052 | | LX00000078 | PLASTIC SLEEVE 6 | 1 | | | | |
| 053 | | LX00000054 | O-RING 10.5X1.8 | 1 | | | | |
| 054 | | LX00000055 | COMPRESSION SPRING 14X15 INOX | 1 | | | | |
| 055 | | LX00000076 | O-RING 9.5X2.65 | 1 | | | | |
| 056 | | LX00000056 | FILTER ASSY | 1 | | | | |
| 057 | | LX00000079 | HOSE ASSY 8MMX6M(5/16"X19.7FT) | 1 | | | | |
| | D10 | | INC. 58-60 | | | | | |
| 058 | | LX00000057 | HOSE END CONNECTOR 8MM(5/16") | 2 | | | | |

A:

Interchange
 O : Yes
 X : No
 < : the new part can be substituted for the current.
 > : the current part can be substituted for the new.
 S : Interchangeable as a set.

