



IN	INDIA
----	-------


Diagram / Parts List

KP312S

312MM PLANER



(IN) KP312S / 312MM PLANER



IN

INDIA

KP312S / 312MM PLANER

Item	Sub	Parts No.	Parts Description	Qty	I/C	E/C No.	Close No.	Remark
001		643700-5	BRUSH HOLDER CAP 7-18	2				
002-1		194991-6	CARBON BRUSH SET CB203	1				
003		911288-6	PAN HEAD SCREW M5X65	4				
004		850360-8	NAME PLATE KP312S	1				
005		153594-5	MOTOR HOUSING COMPLETE	1				
006		636244-2	FIELD 230-240V	1				
007		911248-8	PAN HEAD SCREW M5X28	4				
008		911188-0	PAN HEAD SCREW M4X60	2				
009		911153-9	PAN HEAD SCREW M4X28	2				
010		183585-2	HANDLE SET	1				
	D10		INC. 17					
011		651056-2	SWITCH TG71CR-2	1				
012		695140-3	POWER SUPPLY CORD 1.5-2-10.0	1				
013		682564-2	CORD GUARD	1				
014		687053-2	STRAIN RELIEF	1				
015		265995-6	TAPPING SCREW 4X18	2				
017		183585-2	HANDLE SET	1				
	D10		INC. 10					
018		911248-8	PAN HEAD SCREW M5X28	4				
019		631529-1	SOFT START CIRCUIT	1				
020		652766-4	OVER CURRENT RELAY	1				
021		941102-2	FLAT WASHER 5	2				
022		911942-2	PAN HEAD SCREW M5X95	2				
023		418156-9	BAFFLE PLATE	1				
024		211061-7	BALL BEARING 6000LLB	1				
025		681640-9	INSULATION WASHER	1				
026		516878-6	ARMATURE ASS'Y 220-240V	1				
	D10		INC. 24,25,27,47					
027		241868-7	FAN 82	1				
028		922251-4	HEX. SOCKET HEAD BOLT M5X30	2				
029		317674-3	MOTOR BRACKET	1				
030		256251-5	PIN 4	1				
031		961062-2	STOP RING E-12	1				
032		253010-8	FLAT WASHER 6	2				
033		911211-1	PAN HEAD SCREW M5X12	2				
034		231668-3	TORSION SPRING 15	1				
035		418155-1	FOOT	1				
036		263005-3	RUBBER PIN 6	1				
037		232068-0	LEAF SPRING	1				
038		266026-4	TAPPING SCREW BIND CT 4X12	2				
039		153578-3	SPINDLE COMPLETE	1				
040		961105-0	RETAINING RING S-25	1				
041		211351-8	BALL BEARING 6005LLB	1				
042		211301-3	BALL BEARING 6004LLB	1				
043		961060-6	RETAINING RING S-20	1				
044		213154-6	O RING 14	1				
045		331650-3	COUPLING	1				
046		213154-6	O RING 14	1				
047		211236-8	BALL BEARING 6002DDW	1				
048		345320-8	BLAST DISK	1				
049		911268-2	PAN HEAD SCREW M5X45	3				
050		317673-5	MAIN BRACKET	1				
051		222140-6	V-PULLEY 9-23L	1				
052		252085-4	HEX. NUT M10-17	1				
053		225061-1	POLY V BELT 9-355	1				
054		317676-9	BRACKET COVER	1				
055		317672-7	BELT COVER	1				
056		922431-2	HEX. SOCKET HEAD BOLT M8X20	2				
057		273522-5	FRONT GRIP	1				
058		263005-3	RUBBER PIN 6	1				
059		911248-8	PAN HEAD SCREW M5X28	5				
060		911288-6	PAN HEAD SCREW M5X65	1				
061		911211-1	PAN HEAD SCREW M5X12	2				
062		285023-1	BEARING COVER	1				
063		211236-8	BALL BEARING 6002DDW	1				

A:KP312S(H)

Interchange

O : Yes

X : No

< : the new part can be substituted for the current.

> : the current part can be substituted for the new.

S : Interchangeable as a set.

IN

INDIA

KP312S / 312MM PLANER

Item	Sub	Parts No.	Parts Description	Qty	I/C	E/C No.	Close No.	Remark
064	D10	183570-5	MAIN BASE	1				
			INC. 103					
065		931403-6	HEX. NUT M8	1				
066		252105-4	HEX. LOCK NUT M8-13	1				
067		941201-0	FLAT WASHER 8	1				
068		253877-4	FLAT WASHER 8	1				
069		418177-1	KNOB	1				
070		265511-4	HEX. BOLT	1				
071		417249-9	KNOB COVER	1				
072		345338-9	TIP GUIDE	1				
073		911211-1	PAN HEAD SCREW M5X12	2				
074		317675-1	FRONT BASE	1				
075		251259-4	+ PAN HEAD SCREW M5X16	2				
076		256853-7	ROD 10	1				
077		317668-8	ROLLER HOLDER R	1				
078		214054-3	PLANE BEARING 10	1				
079		331368-6	ROLLER 26-203	1				
080		214054-3	PLANE BEARING 10	1				
081		251259-4	+ PAN HEAD SCREW M5X16	2				
082		317667-0	ROLLER HOLDER L	1				
083		266229-0	H.S.SET SCREW(CUP POINT)M5X8	1				
084		257589-1	SLEEVE 10	2				
085		267198-8	FLAT WASHER 14	2				
086		232076-1	LEAF SPRING	2				
087		922562-7	HEX. SOCKET HEAD BOLT M10X40	2				
088		961062-2	STOP RING E-12	1				
089		324334-0	GUIDE RULE SHAFT	1				
090		345322-4	GUIDE PLATE F	1				
091		266229-0	H.S.SET SCREW(CUP POINT)M5X8	1				
092		231386-3	COMPRESSION SPRING 3	1				
093		216008-6	STEEL BALL 4	1				
094		961062-2	STOP RING E-12	1				
095		812074-7	INDICATION LABEL	1				
096		816393-3	SCALE PLATE	1				
097		251381-7	+ SCREW M5X12	2				
098		211206-7	BALL BEARING 6202LLB	1				
099		317671-9	BEARING BOX	1				
100		251259-4	+ PAN HEAD SCREW M5X16	2				
101		222162-6	V PULLEY 9-39.7	1				
102		265854-4	HEX. SOCKET HEAD BOLT M6X12	1				
103		819084-5	MAKITA LABEL	1				
104		216008-6	STEEL BALL 4	1				
105		231386-3	COMPRESSION SPRING 3	1				
106		266229-0	H.S.SET SCREW(CUP POINT)M5X8	1				
107		324334-0	GUIDE RULE SHAFT	1				
108		345321-6	GUIDE PLATE R	1				
109		961062-2	STOP RING E-12	1				
110		161139-5	DRUM	1				
111		254221-8	KEY 4	1				
112		251212-0	+ FLAT HEAD SCREW M5X13	4				
113		B-02870	HSS PLANER BLADE 312MM	1				
114		345328-2	SET PLATE 310	2				
115		911113-1	PAN HEAD SCREW M4X10 WITH WR	4				
116-1		183621-4	DRUM PLATE SET	1				
117		265484-1	H.S.BUTTON HEAD SCREW M6X17	16				
A01	C10	193733-5	NOZZLE SET	1				
		911248-8	PAN HEAD SCREW M5X28	2				
A02		762001-3	TRIANGULAR RULE	1				
A03		410300-4	JOINT 70	1				
A04		783219-3	HEX. WRENCH 4	1				
F01		410300-4	JOINT 70	1				
F02		193733-5	NOZZLE SET	1				
F03		181575-9	JOINT 70	1				
A:KP312S(H)						Interchange O : Yes X : No < : the new part can be substituted for the current. > : the current part can be substituted for the new. S : Interchangeable as a set.		